



CARE INSTRUCTIONS

Congratulations on purchasing a **HARK BBQ SHEET!**

The Hark BBQ Sheet is totally safe to use. However it is important that you never expose the sheet to an open flame or to a cooking element. The sheet is designed for domestic use only and for temperatures below normal cooking conditions ie 260°C.

Listed below are a few helpful hints to ensure you get the best use out of your Hark BBQ Sheet:

- Before using for the first time, wash the sheet in warm soapy water. Rinse then allow to dry thoroughly.
- Wipe the sheet with a very small amount of oil and then wipe off with a paper towel. This process only needs to be completed once.
- Place the BBQ Sheet on your BBQ hot plate (not on the grill) or on your cooking pan. There is no need to add oil or fat to your food.
- After use, wash your BBQ Sheet hot soapy water and dry the sheet thoroughly. The sheet is also dishwasher safe but must only ever be placed in the top shelf / rack.
- Before storing ensure that your BBQ Sheet is completely dry and either pack it away flat or roll up and store in the box provided. Never fold or crease.